



Części niezbędne do skonstruowania oprawy na bazie profilu WERKIN-KPL.



Profil (A)



Zaślepki (B)



Osłona (C)

Taśma LED (D)


Elementy niezbędne przy czynnościach montażowych:

- klej montażowy


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Wklej taśmę LED (D), umieść osłonę (C), załóż zaślepkę (B).




2. Wyprowadź przewód zasilający. Rozprowadź klej na powierzchni.




3. Podłącz zasilanie do paska LED i wklej profil (A).





Parts needed to mount the TAN-C5 extrusion



Extrusion (A)



End caps (B)



Cover (C)

LED strip (D)


Tools needed for mounting:

-mounting glue


NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure.
More mounting procedures and related accessories can be found

1. Mount the LED strip (D), insert the cover (C), insert the end cap (B).



2. Feed the power cable. Spread the glue on the surface.



3. Connect power to the LED strip and attach the extrusion (A).

