



1. GIZA-LL-T profile (Ref. C2479)
2. GIZA-LL profile (Ref. C0758)
3. Connector*
4. Gland*
5. End cap*
6. Protective insert*
7. Drywall screw
8. Power supply (12 V / 24 V)*
9. Fastener*
10. Steel wire*
11. Ceiling fastener*
12. LED tape*
13. Cover*

NOTE! All LED tapes must be connected to a 12 V or 24 V power supply.


IMPORTANT: Not all possible mounting procedures are presented here.
More mounting procedures and related accessories can be found at
Drawings of extrusions and accessories in these instructions are simplified and only approximate the actual shapes.

Ia




Drill a hole for the power cable in the GIZA-LL-T (1) profile.

IIa



Attach the end cap (5) to the profile and install the gland (4) in the pre-drilled hole.


IIIa



Place the profile on the edge of the drywall board and drill holes through the board and the profile’s flange.


The maximum distance between the holes is 400 mm / 15.75”.

IVa



Insert the drywall screws (7) in the pre-drilled holes and screw the profile flange to the board.

Va




Route the cable from the power supply (8) through the gland.

Install the protective insert (6) in the profile.


Mount the second board.

VIa




Drill holes in the second board and the profile’s flange.

VIIa



Insert the drywall screws (7)
in the newly drilled holes and screw the second flange of the profile to the board.

VIIIa




Apply plaster.

The protective insert keeps the inside of the profile clean.


Make the surface even.

IXa




After the plaster has dried, sand the surface with sandpaper.

Xa




Paint the surface.

XIa




Cut layers of paint and plaster at the junction of the aluminum edge of the profile and the protective insert.

XIIa



Gently remove the protective insert.


XIIIa



Smooth the edges of the profile.


Allow the power cable to extend from inside the profile.

XIVa




Insert the connector (3) into the channel inside the profile and tighten the locking bolts with an Allen key.

Ib




Slide the internal channel of the GIZA-LL profile (2) onto the protruding part of the connector. Finally tighten the connector screws with the Allen key.

IIb



Insert the fastener (9) into the top channel of the profile.


IIIb



Connect the ceiling fastener (10) and the profile fastener with the wire (11).

(For more information on suspension systems, please visit our website).


IVb




Connect the LED tapes to the power supply.

Insert the LED tape (12) in the profile.

Vb



Attach the end cap (5) and the cover (13).




1. Profil GIZA-LL-T (Ref. C2479)
2. Profil GIZA-LL (Ref. C0758)
3. Łącznik*
4. Dławnica*
5. Zaślepka*
6. Wkładka ochronna*
7. Blachowkręt
8. Zasilacz (12 V / 24 V)*
9. Zawieszka*
10. Linka*
11. Zawieszka sufitowa*
12. Taśma LED*
13. Osłona*

UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.


WAŻNE: Instrukcja nie pokazuje wszystkich możliwości montażu. Dodatkowe akcesoria powiązane z produktem wraz z instrukcjami montażu dostępne są na stronie
Rysunki profili i akcesoriów w instrukcji są uproszczone i tylko w przybliżeniu oddają rzeczywiste kształty.

Ia




Wywierć w profilu GIZA-LL-T (1) otwór na przewód zasilający.

IIa



Zamontuj zaślepkę (5) w profilu i dławnicę (4) w nawierconym otworze.


IIIa



Przyłóż profil do krawędzi płyty gipsowo-kartonowej i wywierć otwory, przechodzące przez płytę i kołnierz profilu.


Maksymalna odległość między otworami to 400 mm / 15.75”.

IVa



Wprowadź blachowkręty (7)
do nawierconych otworów
i przykręć nimi kołnierz profilu do płyty.

Va




Przeprowadź przewód z zasilacza (8)
przez dławnicę.

Zamontuj w profilu wkładkę ochronną
(6).


Przyłóż drugą płytę.

VIa




Wywierć otwory w dokładanej płycie
i w kołnierzu profilu.

VIIa



Wprowadź blachowkręty (7)
do nawierconych otworów i przykręć
nimi kołnierz profilu do płyty.

VIIIa




Nałóż gładź gipsową.

Wkładka ochronna zabezpieczy wnętrze profilu przed zabrudzeniem.


Wyrównaj powierzchnię.

IXa




Po wyschnieciu gipsu, wyszlifuj powierzchnię papierem ściernym.

Xa




Pomaluj powierzchnię.

XIa




Natnij warstwy farby i gładzi na styku aluminiowej krawędzi profilu i wkładki ochronnej.

XIIa



Delikatnie usuń wkładkę ochronną.


XIIIa



Wygładź krawędzie profilu.


Wyjmij przewód zasilający z wnętrza profilu.

XIVa




Wprowadź łącznik (3) w kanał wewnątrz profilu i dokręć wkręty blokujące kluczem ampulowym.

Ib




Nałóż profil GIZA-LL (2) kanałem wewnętrznym na wystającą część łącznika. Nastepnie dokręć wkręty łącznika kluczem ampulowym.

IIb



Wsuń zawieszkę (9) w kanał grzbietowy profilu.


IIIb



Połącz zawieszkę sufitową (10) i zawieszkę w profilu linką (11).

(Więcej informacji dotyczących systemów podwieszeń dostępnych jest na stronie internetowej).


IVb



Podłącz taśmy LED do zasilania.

Włóż Taśmę LED (12) do profilu.

Vb



Zamontuj zaślepkę (5) oraz osłonę (13).