


Części niezbędne do skonstruowania oprawy na bazie profilu LINO



Profil (A)



Zaślepki (B)


Osłona (C)

Taśma LED (D)


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.


WAŻNE: Instrukcja przedstawia najbardziej podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie

1. Wklej taśmę LED (D), załóż osłone (C), a następnie załóż zaślepkę (B). Wyprowadź kabel do źródła zasilania.



2. Nanieś taśme obustronną na profil (A), i przyklej profil do powierzchni. Podłącz zasilanie





Parts needed to mount the LINO extrusion



Extrusion (A)



End caps (B)


Cover (C)

LED strip (D)

WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly.
More methods and related accessories can be found at

1. Mount the LED strip (D), insert the cover (C), and then insert the end cap (B). Connect the power cable to the power source



2. Apply the double-sided tape to the extrusion (A), and attach the extrusion to the surface.Connect power

