


Części niezbędne do skonstruowania oprawy na bazie profilu TAMI.



Profil (A)



Zaślepki (B)



Osłona (C)

Taśma LED (D)


Elementy niezbędne przy czynnościach montażowych:

- taśma dwustronnie przylepna


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Wklej taśmę LED (D), umieść osłonę (C), załóż zaślepkę (B).




2. Przyklej taśmę dwustronnie przylepną do profilu(A).



3. Podłącz zasilanie do paska LED i przyklej profil (A) do powierzchni.





Parts needed to mount the TAMI extrusion



Extrusion (A)



End caps (B)



Cover (C)

LED strip (D)


Tools needed for mounting:

- double-sided tape


NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure.
More mounting procedures and related accessories can be found

1. Mount the LED strip (D), insert the cover (C), insert the end cap (B).



2. Apply the double-sided tape to the extrusion (A).



3. Connect power to the LED strip and attach the extrusion (A) to the surface.

