


Części niezbędne do skonstruowania oprawy na bazie profilu OBIT



Profil (A)

Osłona (B)



Osłona (C)



Zaślepka (D)


Taśma LED (E)

Elementy niezbędne przy czynnościach montażowych:


- klej montażowy

UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.


1. Wklej taśmę (D), załóż osłonke (B).




2. Włóż osłone (B) i zaśpekę (C) i wyprowadź przewód zasilający.



3. Nanieś klej w otwór montażowy, podłącz zasilanie, a następnie włóż profil do otworu montażowego.



4.



Parts needed to mount the OBIT extrusion



Extrusion (A)

Cover (B)



Cover (C)



End cap (D)

LED strip (E)


Tools needed for mounting:

- mounting glue


WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly.
More methods and related accessories can be

1. Attach the LED strip (E), insert the cover (C).



2. Insert the cover (B) and end cap (D) Lead out the power cable.



3. Put glue in the mounting channel, connect power, and then insert the extrusion into the mounting channel.

