



Części niezbędne do skonstruowania oprawy na bazie profilu STEKO



Profil (A)



Zaślepka (B)



Sznur silikonowy (C)

Taśma LED (D)

Elementy niezbędne przy czynnościach montażowych:


- wiertarka
- wkrętarka / śrubokręt

UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.


B

Montaż oprawy na bazie profilu STEKO


1. Przewierć profil (A) w miejscu gdzie wyprowadzisz przewód zasilający taśmy LED.




2. Przyklej taśmę LED (D), następnie wyprowadź przewód zasilający przez nawiercony wcześniej otwór.




2. Przymocuj profil (A) do stopnia wkrętami właściwymi dla danego podłoża.




4. Umieść sznur silikonowy (C) w profilu, powyżej taśmy.




5. Załóż zaślepkę (B)





Parts needed to assemble the STEKO Fixture



Extrusion (A)



End cap (B)



Silicone string (C)

LED Tape (D)


Tools needed for mounting:

- drill
- screwdriver


NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure.
More mounting procedures and related accessories can be found


1. Drill a hole in the the extrusion (A) where the power wire will be fed to the LED tape.




2. Mount the LED (D), then run the power wire through the hole drilled earlier.



2. Fasten the extrusion (A) to the surface with appropriate screws for the substrate.



4. Insert the silicone string (C) into the extrusion above the LED tape.



5. Insert the end cap (B).

