




**Części niezbędne do użycia mocownika UCHO-ZD.**



Mocownik (A)




Blokada(B)

**Elementy niezbędne przy czynnościach montażowych:**
**-** klucz ampulowy


**UWAGA!** Lista produktów, z którymi współpracują wybrane akcesoria dostępna jest na stronie

**1.** Wsuń mocowniki (A) w kanał profilu.

A




**2.** Zamontuj linkę montażową na mocownikach.





**3.** Zamocuj blokady (B) w kanale profilu, gdzie znajdują się mocowniki (A). Następnie dokręć śruby w blokadach (B).

B




**4.** Gotowy system montażowy zamontuj na wcześniej przygotowanej powierzchni.






**Parts needed to assemble and mount the UCHO-ZD hanger.**



Hanger (A)




Block(B)

**Tools needed for mounting:**
- Allen wrench


**NOTE!** A list of products corresponding with the selected accessories is available

**1.** Insert the hangers (A) into the channel of the extrusion.

A




**2.** Attach mounting cables to the hangers.



**3.** Insert the blocks (B) into the channel of the extrusion, where the hangers (A) are already attached. Then tighten the screws in the blocks (B).

B



**4.** Mount the ready assembly to the prepared surface.

